

Auto Non-contact Sana Fiber Interferometer

Instruction Manual

V.1

Shenzhen Dimension Technology Co., Ltd
2008.1

General Information

Sana fiber interferometer is independently developed by Dimension Technology with patent, used to measure radius of curvature, Apex offset, Fiber Height and polishing angle, key error of APC connector, in the meantime, show the topography of the connectors and fiber ends directly and clearly.

The main parts of Sana include interferometer, Lenovo table business computer and software package.

Sana adopt 650nm high power LED Light source, which ensure user get clear interference image.


Sana offers two kinds of chucks (2.5mm universal & 1.25mm universal), with which user can test almost all kinds of connectors. 2.5mm universal used to measure FC/PC, SC/PC, ST/PC, E2000/PC, DIN, FC/APC, SC/APC kinds of connectors, 1.25mm universal used to measure LC/PC, MU/PC, LC/APC kinds of connectors, and you don't need to replace chucks and calibrate when you transfer between APC and PC connector measurement, only turning "angle adjuster" to relative angle is ok, very convenient to operate.

Our software has features of accuracy, high repeatability and convenient operability. Before initial test, user should calibrate the unit first. It's very easy to calibration for Sana. When landing calibration interface, turning six points averagely and measuring after focusing accurately, then click "ok" button, it will be automatically calibrated. You don't need to move hard device by yourself, as the software will calibrate inner settings automatically.

Then user can start measurement, only click "measure" button can finish one test, the test result and six historical records will be shown right under the interface, user could decide to save the record or not. If yes the data will be saved in excel format, and it will judge the result qualified or not automatically according to user's criteria or defaulted criteria. In the meantime, the topography of the fiber or connector will be shown on the screen by 3D mesh diagram as well as contour diagram and surface roughness diagram.

Features

- 1 High repeatability, accuracy.
- 2 Convenient hardware and software operability.
 - Don't need to change chucks when transfer between APC and PC connector measurement.
 - When calibration, software will calibrate automatically, user don't need to move the unit.
- 3 With patent, easily fasten chucks, Unique APC Fluctuate locate technology made the measurement never more precisely.
- 4 3D-Mesh diagram and analysis chart directly reflect fiber or connectors details.
- 5 Test report and data will be saved in excel format, easy for document management and print out.
- 6 Absolutely competitive price.



Configuration and accessories

- 1 1x Interferometer
- 2 1x Lenovo table computer
- 3 2x chucks(LC universal and SC universal)
- 4 2x APC locator clamps (FC/APC ,SC/APC,)
- 5 2x calibration connectors +Standard Utensil
- 6 1x toolset
- 7 1x RS232 cable
- 8 1x power cable
- 9 1x software set
- 10 1x User manual

Parameters


Repeatability	ROC	0.3mm
	Fiber height	8nm
	Apex offset	2um
	Angle	0.02deg
Stability	ROC	0.5mm
	Fiber height	12nm
	Apex offset	5um
	Angle	0.03deg
Working Temperature	-10℃~30℃	
Zoom time	10X	
Resolution	1um	
Wavelength	650nm	
Power supply	12V	
Dimension	44cm*22.5cm*17.5cm (L * W * H)	

II Installation

2.1 Sana operation panel introduction

Sana hardware for user operate includes: back panel, chucks worktable and mirror control hole three parts

2.1.1 as shown on picture 5:



Picture 5 Chucks worktable


2.1.2 Sana Back Panel as shown on picture 6:

DC 12V power receptacle, data cable receptacle RS232, VIDEO Out receptacle VIDEO OUT and on/off switch



Picture 6 Sana Back Panel

2.1.3 Mirror control hole as picture 7:



Picture 7 Sana Mirror control hole

2.2 Hardware assembly

Please take out the Sana interferometer onto firmness stage with power in “off” status, plug data cable RS232 into RS232 receptacle, the other terminal connect it with PC, plug 1394 data cable into VIDEO OUT receptacle, the other terminal connect to capture card of PC, insert DC 12V into sana receptacle..

2.3 Software Installation

Insert USB key into USB receptacle of PC, follow below procedure:

2.3.1 Support Office 2003 installation, follow installation guide offered by Microsoft.

2.3.2 Matlab installation. There are three discs in Matlab, just install the first one is ok.

2.3.3 Capture card driver installation:


Install windows patch 《dotnetfx.exe》 and 《WindowsXP-KB885222-v2-x86-CHS.exe》 wich under folder 《poitgreycapture card driver》 , then install PGRInstallBase.exe under folder 《PointGrey》 .

2.3.4 Dimension Sana interferometry software installation, click Dimension Sana software and install as instructed.

2.3.5 After all software installation finshed please startup Matlab program first, then exit after completness, then running Dimension Sana interferometry software.

2.4 Dimension Sana interferometry software interface.


Dimension Sana interferometry interface as shown on picture 8, which includes main menu, live image, information setting parts and live report.



Picture 8 Dimension Sana interferometry interface

2.4.1 Setup

After running Dimension Sana interferometry software, setup by main menu or hotkey "setup".



The first item is company name.

The second item is calculation region, Fiber Dia means dia of the fiber connector to be measured, the rest two are the calculation region, usually user don't need to re-set them. The defaulted setting for them are: Region(um): 180, Region (um): 140, AvgDia (um): 100.

The third item is measurement criteria setup, three criterias for selection, IEC, Telicordia and user customized criteria, if customized, please save the criteria and next time you may load it automatically(the format of the file must be .ini)

The fourth item is "data save set", measurement data and single measurement report method and path setup could be setted in this item. "auto" "ask" and "off" three ways for option. **Attention:Date and report must save in a folder,not in harddisk root directory.**

2.4.2 Information setup as shown on picture 12.

The 'Informations' dialog box contains the following fields and options:

- Connector Type: SC/PC (dropdown menu)
- Connector ID: ☒ Auto Inc ☐ Custom
- Auto Save Data: Auto (dropdown menu)
- Auto Print Report: Off (dropdown menu)
- Filename: aotu (text input)
- Connector: (empty text input)

Picture 12 information setup

Connector type: select relative fiber type to be measured.


Connector ID: two options, "auto Inc" means system will auto design connector ID by increased number, "custom" is designed by user everytime before measurement in "result" item input connector ID as shown on picture 13

The 'Result' dialog box displays the following measurement results:

- Connector ID: 940
- Radius of Curv(mm): 18.55
- ApexOff(μm): 57.69
- Fiber Height(nm): 47
- APC_Angle(deg): FALSE

Picture 13

2.4.3 Hot keys as shown on picture14



picture14

How to use Sana interferometer


3.1 Chuck Setting

There are two chucks included, one is 2.5mm universal, the other one is 1.25mm universal, 2.5mm universal truck used to measure SC/UPC、FC/UPC、ST/UPC、E2000/UPC、DIN、SC/APC、FC/APC、E2000/APC connectors, 1.25mm universal chuck is used to measure LC、MU connector.

1. How to set 2.5mm fiber connector

insert 2.5mm fiber connector into 2.5mm universal chuck and lock it by turning connector locker, Make sure angle is in 0 degree by checking angle bar and the moving base is locked, slightly turn the chuck to bottom right direction to make the chuck closely in touch with horizontal adjuster and vertical adjuster as shown on picture 15.

Attention: chuck station must be horizontal!



Picture 15

Turning focusing knob till get sharp image, then turning horizontal adjuster and vertical adjuster till the image within live round circle, then lock chuck fastener.

1.25mm fiber connection installation is the same way as 2.5mm fiber connector.

3.2 Calibration

Please re-calibrate in case of replacing chuck or big difference of figure “apex offset”, insert calibration connector to chuck station and lock it fastenly, turning focusing knob till get sharp interferometry image, click “calibrate” to get into calibration interface, as shown on picture 16.

Please pay attention to following points when calibration:

- 1 set “Angel “ to 0 degree by truning “angle adjuster”.**
- 2. the former part of “angle adjuster” must closely in touch with turning panel, if no please unlock the turning panel locker first, set again till they are in closely touch with each other then lock angel adjuster;**
- 3. the chuck panel should be locked when Sana operating;**
- 4. calibration connector should be locked when calibrating or measuring;**
- 5. Turning 6 times to fulfill calibration, each time turning 60degree.**




picture16

Calibration Procedure:

1. Insert alibrate connector,lock “chuck fastener” and turning “focusing knob” till get the most sharp image;
2. Press “ measure” to fulfill the first test, then unlock fiber connector and turning 60 degree lock it again to measure the second time, measure six times in total by this way.
3. The system will calculate the warp automatically, the warp of X axis will shown on

"X_Apexoff(um) """, the warp of Y axis will shown on Y_Apexoff(um), if any of the figure larger than 10um the system will remind user to turn the direction mirror as shown on picture 17, after done please re-calibrate the system till the two figures within 10um, press OK to save the calibration figure and date repaired as shown on picture 18, if user don't turn director mirror as picture 17, the system will repair the warp automatically as well.



picture17

4. Press Ok as shown on picture 18 to save calibration data and exit calibration interface.



picture18

3.3 Measurement: UPC fiber connector

User may start measurement after chuck installation and calibration, before measurement please setup judgement criteria and data saving path.

3.3.1 Judgement criteria setup

User may setup criteria by main menu or hotkey"setup", choose criteria in need from IEC、telicordia or Custom, if you select custom, please input the figure and press "save as" to save the data(the saved file format must in .ini).

3.3.2 Data saving setup

Data saving includes,measurement data and single measurement report method and path setup could be setted in this item. "auto" "ask" and "off" three ways for option. **Attention: Date and report must save in a folder,not in harddisk root directory.**

Data saving may carry out by main menu and hotkey"setup", details as below: Auto means auto save as defaulted; ask means if user want to save or not; off means don't save.

3.3.3 Image brightness setup

Click "Image" under main menu, right click " Video set" to fulfill brightness setup.

3.3.4 Measurement-UPC fiber connector

User may start measurement after finish all parameter setup, Before start please make sure the fiber connector endface is clean(it will effect test result if not

clean) . insert fiber connector to sana chuck and lock it, turning focusing knob till get sharp interferometry image, then click “ measurement” key or F12 directly to start measurement.

Measurement result will be created at the bottom right of the interface as shown on picture19, the worst figure will be shown in red color to remind user and the system will judge the result pass or not automatically, the lastest six historical records will be shown directly under the interferometry interface.as shown on picture 20.

Result

Connector ID: 940

Radius of Curv(mm): 18.55

ApexOff(μm): 57.69

Fiber Height(μm): 47

APC_Angle(deg): \

FALSE

picture 19

Item	Connector	ID	ROC (mm)	Apexoff (μm)	FiberH(μm)	Angle(")	Judge
4		940	18.55	57.69	47	\	FALSE
3		939	18.62	57.69	50	\	FALSE
2		938	18.74	57.88	51	\	FALSE
1		937	19.00	52.33	59	\	FALSE

picture 20

3.4 APC connector measurement

When measuring APC fiber conenctor user don't need to replace chuck or re-calibrate, just unlock “turning base locker” and turn “ angle adjuster” to 8 degree, then lock the turning base, insert APC locator clamp into chuck groove.

After insert fiber connector please turn focusing knob till get sharp image, if the fiber image out of live round circle more then 1/3 user need to just the chuck position to turn it in circle . (the chuck station should in horizontal).

Attention: choose “APC” connector type in information setup interface.

Care and Maintenance

4.1 Care and maintenance

1. Keep Sana free from severe sources of vibration. Do not place the unit where it is vulnerable to be knocked or physically damaged,
2. Turning 60 degree each time when calibration, and focusing live image accurately;
3. Fiber connector endface must be clean.;
4. If it's very tight when insert fiber connector please check if glue or same kinds of dirty stick on fiber ferrule.

4.2 Please contact **Dimension Technology** if any after-service problem.